



MEDIAVAULT™

IMPORTANT PRODUCT INFORMATION PLEASE READ AND SAVE THIS DOCUMENT


THANK YOU FOR PURCHASING THIS FIREKING® MEDIAVAULT® HD

MediaVault HD (MVHD) is uniquely designed to protect your on-site data backups in a UL®-Rated fire resistant container even if your computer is destroyed. Simply connect the USB cable (two twin-lead 4 foot USB cables are provided) between the MVHD and your PC or Macintosh computer and begin using its external storage capability.¹ Your MVHD is protected by a 3-Year Limited Warranty. Your MVHD protects your data with the UL Class-125 1-Hour Fire Rating. External hard drives installed in your MVHD¹ are designed to be operated with the MVHD closed and locked for added theft protection and full-time fire protection. A powerful and easy to use backup software suite² (a \$69.⁹⁵ value) is also included at no additional cost.



¹One 250 GB drive is provided with the MVHD-250; two 250 GB drives are provided with the MVHD-500.


²Microsoft Windows only.



MVHD Interior
USB Cables "A" and "B"



Connect First Hard Drive to
Internal USB Cable "A"



MVHD
Two Drives Installed

MVHD SETUP

It takes just minutes to unpack, setup, and begin using your MediaVault HD. To get started, just follow these simple steps:

1. Unpack and Check

Open and inspect the contents of your MVHD. One large box holds the MVHD fireproof container. A second box will contain documentation, two four-foot twin-lead USB cables, keys, backup software, and your Seagate hard drive(s).

2. Install Drives

Open the MVHD lid. Connect your first hard drive to the interior USB cable marked "A". Slide the hard drive into the foam slot closest to the rear of the MVHD. If you are installing a second hard drive: connect it to the USB cable marked "B", then slide it into the second foam slot. For maximum protection, close and lock the MVHD.

3. Connect Computer

Place your MVHD such that the rear of the MVHD is within four feet of available USB ports on your computer.

If you have only one hard drive: Connect one external USB cable⁴ between your computer and the MVHD rear port "A".




USB Ports

If you have two hard drives: Connect both external USB cables⁴ between your computer and the MVHD rear USB ports.

Your operating system should automatically find each 250 GB drive and assign each its own drive letter.

⁴You must use the USB cable provided with the MVHD. Standard USB cables may not work. The Auxiliary Power plug should only be connected to the computer if the computer does not detect the external hard drive without it.



- 1 – Plug into the MVHD USB port.
- 2 – Plugs into computer USB port.
- 3 – Auxiliary USB power (only required for computers having low USB output power).
- 4 – USB pass-through.



MVHD Connected to PC
(One USB connection shown)

MVHD OPERATION

Your MVHD is designed to allow full-load operation of one or two hard drives with the lid closed. The empty space inside the MVHD may be used to store other computer media.

BACKUP SOFTWARE

The complimentary third-party backup software provided with your MVHD purchase is a full backup suite (Windows only). Although you may use any backup software you desire, the software provided with your MVHD offers an easy to use interface, full featured suite, and Microsoft Windows compatibility. When creating backups you have numerous options including what to backup, where to back it up (including drive spanning), and when to run the backup (immediately and/or scheduled). Refer to the extensive built in help and tutorial files for detailed information about how to manage your backups.

Installation

Insert the third-party PC backup software CD into your CD-ROM drive. The setup wizard will launch automatically. Follow on-screen directions to complete installation and launch the application.

Registration

When you launch the software for the first time, register the software using the license key provided with the disk (Select "Registration" from the "Help" menu). The license key number is printed on the disk or disk sleeve. Use the software help system as needed to assist you in configuring your complimentary backup software.

For additional information visit www.MediaVaultHD.com.

AFTER A FIRE...

In the event of a catastrophic fire all data stored on the hard drives inside the MVHD are protected. Unlike competitive solutions, there is no need to send your product to a third-party lab to salvage data. Data recovery time is limited only by how quickly you can open the MVHD container. Visit www.MediaVaultHD.com for additional information about post-fire container opening techniques.



©2008 FireKing® Security Group

*FireKing® is a registered trademark and MediaVault™ is a trademark of FireKing® International, LLC.
Other trademarks are property of their respective companies.*

101 Security Parkway • New Albany IN 47150

www.MediaVaultHD.com

Doc 513740 • Rev 9/2008